


Jasmine TM-R501 Turntable Motor setup instructions

The TM-R501 include a micro-controller chip on the control board, The speed adjusted by a coding switch, not by a traditional resistor switch. Each step you turn the switch change a little speed, that is the base to let the motor reach a precise speed.

Please give your patience to turn the switch more circles, you will reach the speed you want. Then, let the motor run one minute , the micro-controller chip will remember the speed you setup, next time you just need to power on/off the motor.

Setup instructions



- Step 1:
- Install the belt,
 - Put a stroboscope disc on the platter,
 - Power on the stroboscope lamp
 - power on the motor.



- Step 2:
- Turn the speed selector to the 33 1/3 rpm position.
 - Tune the speed adjustment knob till the speed reach the 33 1/3 rpm.
- Step 3:
- Turn the speed selector to the 45 rpm position.
 - Tune the speed adjustment knob till the speed reach the 45 rpm.
- Step 4:
- After the motor run several minutes, toggle the speed selector to confirm the speed you setup is correct and steady. If not, repeat step 2 and step 3.